



2016 Covert Code Black 12.0 Wireless Camera

1. Login to <https://secure.covert-wireless.com>
2. Select new user to create your customized login. For existing using users, login with your email address and password.
3. Enter your personal information and your billing information.
4. Enter your IMEI number from the camera and the ICCID number from the SIM card. This is to identify the device being activated. It can be found on the outside packaging of your camera as well as the inside sticker of the device.
5. Choose your plan.

Downloading the Mobile App:

Search "**Covert Wireless**" in your Google Play Store or Apple App Store.



Accessing the Web Portal:

Open your web browser to:

www.covert-wireless.com



Note: You cannot use an old SIM card or add the cameras to an existing plan.

For more instructions, helpful tips or support, please visit our website at www.covertscoutingcameras.com, email our support staff at support@dlccovert.com or call our toll-free number at 877-462-1799.

Note: You may cancel your monthly plan anytime by calling 877-462-1799, emailing support@dlccovert.com, or logging into the web-portal.